



baby safety first!

- Always use this product with adult supervision.
- Never use feeding teats as a soother. Continuous and prolonged sucking of fluids will cause tooth decay.
- Keep all components not in use out of the reach of children.
- Before first use, clean the product thoroughly. Inspect before each use and pull feeding teats in all directions to check for cracks.



Precision Fit



Store Safely



Anti-Colic System



Natural Shape

- Do not store a feeding teat in direct sunlight or heat, or leave in disinfectant (sterilizing solution) for longer than recommended, as this may weaken the teat.
- Before first usage place in boiling water for 5 mins. This is to ensure hygiene.
- Do not warm contents in a microwave oven, as this may cause uneven heating and could scald your baby.
- Dishwasher-safe colouring may discolour components.
- Don't allow children to play with small parts or walk/run while using bottles or cups.
- Drinks other than milk and water, such as fruit juices and flavoured sugary drinks are not recommended. If used, they should be well diluted, only used with this polypropylene bottle in the refrigerator for up to 48 hours (not in the door) or in the freezer for up to 3 months.
- Never refreeze breast milk or add fresh breast milk to already frozen milk. Do not use abrasive cleaning agents or anti-bacterial cleaners.
- Do not place components directly on surfaces that have been cleaned with anti-bacterial cleaners. Excessive concentration of detergents may cause plastic components to crack. Should this occur please replace immediately.
- Plastic material properties may be affected by sterilizing and high temperatures. This can affect the fit of the bottle cap.


Cleaning: Before first use, disassemble all parts, clean and sterilize the product. After every use, take all items, wash in warm soap water and rinse thoroughly. Make sure that you wash your hands thoroughly and that the surfaces are clean before contact with the sterilized components of the bottle.

Assembly: When you assemble the bottles, make sure you place the cap vertically onto the bottle so that the teat sits upright. To remove the cap, place your hand over the cap and unscrew in an anticlockwise direction. Place the teat spout under the cap and pull it up in a straight line. Make sure that you pull the teat through completely, until its lower part is even with the screw ring.

Maintenance: Before each use, inspect all bottle components. Pull the feeding teat in all directions. For optimum performance, pinch & massage the teat between index finger and thumb prior to a feed. For hygiene reasons, we recommend replacing nipples every 3 months. Keep teats in a dry, covered container. When not in use, do not store in direct sunlight or heat, or leave in disinfectant (sterilizing solution) for longer than recommended, as this may weaken the teat. Don't place in a heated oven.

Compatibility: Make sure you use the correct nipple with the correct flow rate when you feed your baby.

HEAD OFFICE:
39 Overport Dr,
Essenwood,
Berea, 4091
South Africa
Tel: +27 (31) 208 1980
Fax: +27 (31) 208 2762



Air Flow-Tech
Anti-Colic System

Precision Fit

Natural Shape

Easy Grip Design

